



TELINK SEMICONDUCTOR

Application Note : Telink Burning and Debugging Tool (BDT) User Guide

AN-18101200-E2

Ver 1.1.0

2019/8/22

Brief:

This document is the user guide for Telink Burning and Debugging Tool (BDT).

Published by
Telink Semiconductor

**Bldg 3, 1500 Zuchongzhi Rd,
Zhangjiang Hi-Tech Park, Shanghai, China**

© Telink Semiconductor
All Right Reserved

Legal Disclaimer

Telink Semiconductor reserves the right to make changes without further notice to any products herein to improve reliability, function or design. Telink Semiconductor disclaims any and all liability for any errors, inaccuracies or incompleteness contained herein or in any other disclosure relating to any product.

Telink Semiconductor does not assume any liability arising out of the application or use of any product or circuit described herein; neither does it convey any license under its patent rights, nor the rights of others

The products shown herein are not designed for use in medical, life-saving, or life-sustaining applications. Customers using or selling Telink Semiconductor products not expressly indicated for use in such applications do so entirely at their own risk and agree to fully indemnify Telink Semiconductor for any damages arising or resulting from such use or sale.

Information:

For further information on the technology, product and business term, please contact Telink Semiconductor Company (www.telink-semi.com).

For sales or technical support, please send email to the address of:

telinknsales@telink-semi.com

telinknsupport@telink-semi.com

Revision History

Version	Major Changes	Date	Author
1.0.0	Initial release	2018/10	LJW, PT, Ryan, Cynthia
1.1.0	1. Support Multi-devices 2. Added timestamp 3. Path space problem 4. Path buffer overflow etc.	2019/8	LJW, JF

Table of contents

1	Brief Introduction	7
1.1	Function Overview	7
2	Operation Guide	8
2.1	Download firmware.....	8
2.1.1	Connect hardware	8
2.1.2	Connect Device	11
2.1.3	Download FW into “FLASH” via “USB” mode	13
2.1.4	Download FW into “FLASH” via “EVK” mode	21
2.1.5	Download FW into “SRAM” or “OTP”	30
2.1.6	Multi-address Download.....	31
2.2	Flash sector erase	36
2.3	Activate MCU	40
2.4	Debug.....	41
2.4.1	Access memory.....	42
2.4.1.1	Read data from memory space	42
2.4.1.2	Write data into memory space.....	46
2.4.2	Operate Variable List.....	50
2.4.2.1	Update variable list.....	51
2.4.2.2	Sort variables	52
2.4.2.3	View variable above 4 bytes	53
2.4.2.4	Modify variable value.....	54
2.4.3	Debug MCU	57
2.4.3.1	Run MCU	57
2.4.3.2	Pause MCU	58
2.4.3.3	Step MCU	59
2.4.3.4	Trace PC	62
2.4.3.5	Stall MCU.....	64
2.4.3.6	Start MCU.....	65
2.5	Single-wire synchronization	66
2.6	Command line	68
2.6.1	Single command line	68
2.6.2	Multi-command line.....	70
2.7	Log windows.....	71

2.8	Help.....	73
2.9	Default configuration	76
3	Upgrade Firmware.....	78
4	Function Support List.....	80

Table of figures

Figure 1-1	Main interface	7
Figure 2-1	Connect target board with PC directly.....	8
Figure 2-2	Connect “ Burning EVK ” with PC.....	9
Figure 2-3	Connect target board with “ Burning EVK ” via USB	9
Figure 2-4	Connect target board with “ Burning EVK ” via Swire.....	10
Figure 2-5	Burning and Debugging Tool.....	11
Figure 2-6	Check Available Device	12
Figure 2-7	Select the Specified Device.....	13
Figure 2-8	Select chip type	14
Figure 2-9	Select download mode as “USB”	15
Figure 2-10	Select starting offset address.....	16
Figure 2-11	Open file select window.....	17
Figure 2-12	Select target file and open new file path.....	17
Figure 2-13	Directly select target file path in the submenu of “Reopen”	18
Figure 2-14	Connection status indication	19
Figure 2-15	Download FW into Flash via USB mode	20
Figure 2-16	Manual MCU reset	21
Figure 2-17	Auto MCU reset	21
Figure 2-18	Select Chip Type	22
Figure 2-19	Select download mode as “EVK”	23
Figure 2-20	Open the Setting Dialog.....	24
Figure 2-21	Select the Target File.....	25
Figure 2-22	Select bin File.....	25
Figure 2-23	Check Connection Status	26
Figure 2-24	Download FW into Flash via “ Burning EVK ” mode	27
Figure 2-25	Manual MCU reset	28
Figure 2-26	Auto MCU reset	29
Figure 2-27	Download firmware to “SRAM” via “auto mode”	30
Figure 2-28	Select destination space	31
Figure 2-29	Open “Multi-address Download” interface.....	32
Figure 2-30	Add FW	33
Figure 2-31	Set offset address	34
Figure 2-32	Start downloading	35
Figure 2-33	Reset.....	36
Figure 2-34	Select starting address	37

Figure 2-35	Set erase size.....	38
Figure 2-36	Erase 512kB flash space starting from 0x000000.....	39
Figure 2-37	Activate MCU	40
Figure 2-38	“Memory Access” interface	41
Figure 2-40	Set operation destination and size	43
Figure 2-41	Set starting address and initiate reading	44
Figure 2-42	Save read data	45
Figure 2-43	Memory Access Window	46
Figure 2-44	Set Operation Size	47
Figure 2-45	Offset of the Starting Address	48
Figure 2-46	Set data and initiate writing.....	49
Figure 2-47	Update variable list.....	51
Figure 2-48	Sort variable by name	52
Figure 2-49	Read variable value more than 4 bytes.....	53
Figure 2-50	Double click specified “Value” box.....	54
Figure 2-51	Modify variable value.....	55
Figure 2-52	Write data to specified address.....	56
Figure 2-53	Run MCU	57
Figure 2-54	Pause MCU	58
Figure 2-55	Step MCU in “Single step” mode	59
Figure 2-56	Step MCU in “continuous” mode	60
Figure 2-57	Select “interp .lst”	61
Figure 2-58	Step MCU with “interp .lst” selected in “Single step” mode.....	61
Figure 2-59	Step MCU with “interp .lst” selected in “continuous” mode	61
Figure 2-60	Trace PC in “Single step” mode.....	62
Figure 2-62	Switch “Single step” mode to “continuous” mode	63
Figure 2-64	Stall MCU.....	64
Figure 2-65	Start MCU	65
Figure 2-66	Set Swire synchronization speed	66
Figure 2-67	Open cmdline input window	68
Figure 2-68	Enter single command line	69
Figure 2-69	Enter multiple commands.....	70
Figure 2-70	Open usb log windows.....	71
Figure 2-71	Display output characters	72
Figure 2-72	Exit usb log mode	72
Figure 2-73	Show all commands.....	73
Figure 2-74	Open Help document	74
Figure 2-75	Get information about Telink.....	75
Figure 3-1	“Upgrade EVK” window	78
Figure 3-2	Check current FW version.....	78
Figure 3-3	Load new FW	79
Figure 3-4	Upgrade FW into EVK	79

Table of figures

Table 4-1 Function Support List.....	80
--------------------------------------	----

1 Brief Introduction

“Telink Burning and Debugging Tool (BDT)” applies to all engineers who want to develop applications based on Telink SoCs including 8267, 8269, 8266, 8232, 8233, 8366, 8368 and 8x5x series.

This document presents the guide on how to use “Telink Burning and Debugging Tool (BDT)”.

1.1 Function Overview

During SDK development, by using “Telink Burning and Debugging Tool (BDT)”, firmware can be directly downloaded into the target board (e.g. development board) via USB mode or “Burning EVK” (abbreviated as EVK) mode.

Its main functions include “Erase flash sector”, “Download firmware”, “Activate MCU when communication failed”, “Access memory space including FLASH /CORE /ANALOG /OTP”, “Read/Write global variable” and “View USB log”.




Figure 1-1 Main interface

2 Operation Guide

2.1 Download firmware

2.1.1 Connect hardware

Before using “**Telink Burning and Debugging Tool (BDT)**”, it’s needed to connect the target board with PC.

There are two methods to connect the target board with PC, as shown below.

Method 1: Directly connect the target board with PC via USB.

This method only applies to target board with USB interface and MCU supporting USB function, e.g. a dongle board.



Figure 2-1 Connect target board with PC directly

Method 2: Connect the target board with PC via Telink “**Burning EVK**” TLSR8266BR56.

- 1) Connect the “**Burning EVK**” with PC via USB cable. Observe the indicating lights of the “**Burning EVK**”: The indicating lights will blink once to indicate that the “**Burning EVK**” and its connection with PC is OK.



Figure 2-2 Connect “**Burning EVK**” with PC

2) Connect target board with “**Burning EVK**”.

There are two methods to connect the target board with the “**Burning EVK**”.

- a) Connect the target board with the “**Burning EVK**” via USB interface directly, as shown below. This connection method only applies to target board with USB interface and MCU supporting USB function, e.g. a dongle board.



Figure 2-3 Connect target board with “**Burning EVK**” via USB

- b) Connect the target board with the “**Burning EVK**” via Swire (Single wire) interface, as shown below.



Figure 2-4 Connect target board with “**Burning EVK**” via Swire

Please refer to Telink document “**AN_18010500_User Guide for Telink Burning EVK TLSR8266BR56**” for the detailed guide of TLSR8266BR56.

After connecting the target board to PC via USB method or “**Burning EVK**” method, there are two methods to download firmware into the target board, which respectively correspond to the two hardware connection methods above.

2.1.2 Connect Device

Before downloading firmware into the target board, please ensure that the device have been found by BDT as the following figure.




Figure 2-5 Burning and Debugging Tool

If BDT do not find device as the following figure, you can Click “Refresh” to check available device.




Figure 2-6 Check Available Device

If BDT find many devices, all devices will be listed as the following figure. After clicking the button “Refresh”, the first device will be connected to BDT by default. If you want to connect other devices, you can select the specified device as the following figure.




Figure 2-7 Select the Specified Device

2.1.3 Download FW into “FLASH” via “USB” mode

Before using “USB” mode to download or debug MCU, please ensure that the specified MCU supports USB function and its USB function is available. Refer to section **4 Function Support List** for details.

Then user can follow the guide in this section to download firmware into specific flash space of the target board via “USB” mode.

Step1: Select chip type of the target board, e.g. 8258 (default option). The following two methods are supported.

- ✧ Method 1: Use the drop-down menu to select chip type.
- ✧ Method 2: Press the shortcut key combination “Ctrl + Q” to switch chip type.

*Note: All chip type options and default option are configurable in the “config.ini” file.




Figure 2-8 Select chip type

Step2: Select download mode as “USB”. The following two methods are supported.

- ✧ Method 1: Use the drop-down menu to select USB download mode.
- ✧ Method 2: Press the shortcut key combination “Ctrl + W” to switch to USB download mode. The drop-down menu will automatically show the current download mode after each switch.

*Note: All download mode options and default option are configurable in the “config.ini” file.




Figure 2-9 Select download mode as “USB”

Step3: Click the “Setting” button to open the Setting dialog window. Select the “FLASH” setting option. User can adopt either of the following two methods to set the offset of flash starting address for target firmware storage, e.g. 0x000000 (default option).

- ✧ Method 1: Use the drop-down menu of “Download Addr” to select the offset option available.
- ✧ Method 2: Input the offset address in the editable box of “Download Addr”.

*Notes:

- 1) All setting options and default option are configurable in the “**config.ini**” file.
- 2) User can also configure the “SRAM”/“OTP” setting option so as to download target firmware to destination area in SRAM or OTP.




Figure 2-10 Select starting offset address

Step4: Select the target firmware file to be downloaded into the target board.

1) Click **File->Open** to open the file select window.




Figure 2-11 Open file select window

2) On the file select window, select the target bin file (e.g. Telink.bin) and then click the “**Open**” button.




Figure 2-12 Select target file and open new file path

The file path will be displayed at the bottom of the main interface. Every time when a new file path is opened via the file select window, it will be added to the submenu of “File->Reopen”. This simplifies FW selection in subsequent operations by enabling user to directly select the target file path available in the submenu of “Reopen”.




Figure 2-13 Directly select target file path in the submenu of “Reopen”

Step5: Check connection status between the target board and the PC and make sure it's OK.

- ✧ If the status of connection is OK, the left bottom of the main interface will show “usb device: ok” or “evk device: ok”.
- ✧ If the left bottom of the main interface shows “usb device: not found”, it indicates the connection between the target board and the PC is not available.




Figure 2-14 Connection status indication

Step6: Download the selected file into the target board.

By clicking the “Download” button, the selected firmware file will be downloaded into the specified flash space of the target board via USB mode. The log window will indicate corresponding log information, as shown below.




Figure 2-15 Download FW into Flash via USB mode

Step7: Reset MCU to make the newly-downloaded program run without the need to power cycle MCU (unplug/plug from Burning EVK). User can follow either of the following two methods to make MCU boot and run.

- ✧ If “manual mode” is selected via the drop-down menu, after FW burning user can click the “Reset” button at the top right corner of the tool to manually reset the MCU.




Figure 2-16 Manual MCU reset

- ✧ User can also select “auto mode” via the drop-down menu before FW burning, so as to enable auto reset after FW burning.




Figure 2-17 Auto MCU reset

2.1.4 Download FW into “FLASH” via “EVK” mode

Before using “EVK” mode to download firmware, please ensure that target board is connected to PC via “Burning EVK” method and the single wire communication of

the target board is established.

User can follow the guide in this section to download firmware into specific flash space of the target board via “EVK” mode.

Step1: Select chip type of the target board, e.g. 8258 (default option). The following two methods are supported.

- ✧ Method 1: Use the drop-down menu to select chip type.
- ✧ Method 2: Press the shortcut key combination “Ctrl + Q” to switch chip type. The drop-down menu will automatically show the current type after each switch.

*Note: All chip type options and default option are configurable in the “config.ini” file.




Figure 2-18 Select Chip Type

Step2: Select download mode as “EVK”. The following two methods are supported.

- ✧ Method 1: Use the drop-down menu to select EVK download mode.
- ✧ Method 2: Press the shortcut key combination “Ctrl + W” to switch to EVK download mode. The drop-down menu will automatically show the current download mode after each switch.

*Note: All download mode options and default option are configurable in the “config.ini” file.




Figure 2-19 Select download mode as “EVK”

Step3: Click the “**Setting**” button to open the Setting dialog. Select the “**FLASH**” setting option. User can adopt either of the following two methods to set the offset of flash starting address for target firmware storage, e.g. 0x000000 (default option).

- ✧ Method 1: Use the drop-down menu of “Download Addr” to select the offset option available.
- ✧ Method 2: Input the offset address in the editable box of “Download Addr”.

*Notes:

- 1) All setting options and default option are configurable in the “**config.ini**” file.
- 2) User can also configure the “**SRAM**”/“**OTP**” setting option so as to download target firmware to destination area in SRAM or OTP.




Figure 2-20 Open the Setting Dialog

Step4: Select the target firmware file to be downloaded into the target board.

User can select the target file via the “**File->Open**”, or via the “**File->Reopen**” if it’s available in the submenu. The file path will be visible at the bottom of the main interface.




Figure 2-21 Select the Target File




Figure 2-22 Select bin File

Step5: Check connection status between the target board and the PC and make sure it's OK.

- ✧ If the status of connection is OK, the left bottom of the main interface will show “usb device: ok” or “evk device: ok”.
- ✧ If the left bottom of the main interface shows “usb device: not found”, it indicates the connection between the target board and the PC is not available.




Figure 2-23 Check Connection Status

Step6: Download the selected file into the target board.

By clicking the “Download” button, the selected firmware file will be downloaded into the specified flash space of the target board via EVK mode. The log window will indicate corresponding log information, as shown below.




Figure 2-24 Download FW into Flash via “Burning EVK” mode

Step7: Reset MCU to make the newly-downloaded program run without the need to power down MCU. User can following either of the following two methods to make MCU boot and run.

- ✧ If “manual mode” is selected via the drop-down menu, after FW burning user can click the “Reset” button at the top right corner of the tool to manually reset the MCU.
- ✧ User can also select “auto mode” via the drop-down menu before FW burning, so as to enable auto reset after FW burning.




Figure 2-25 Manual MCU reset




Figure 2-26 Auto MCU reset

2.1.5 Download FW into “SRAM” or “OTP”

By default, the “Setting” option is set as “Flash”, i.e. by clicking the “Download” button, the target firmware will be downloaded into the target board’s “Flash” space.

User can also change the “Setting” option to “SRAM” or “OTP”. In this case, by clicking the “Download” button, the target firmware will be downloaded into the target board’s “SRAM” or “OTP” space correspondingly.

For the TLSR8258, the starting SRAM address for target firmware is 0x040000. For other Telink’s SoCs, the starting SRAM address for target firmware is 0x008000. Of course, user can set other address as needed in the editable box.

After the target file is downloaded successfully, the target board will not automatically run the new FW in “manual mode”, so user needs to click the “Reset” button to make program boot. User can also select “auto mode” via the drop-down menu before downloading, so as to enable auto MCU reset.




Figure 2-27 Download firmware to “SRAM” via “auto mode”

If target board supports OTP function, user can download firmware into “OTP”. Refer to section 4 **Function Support List** for details.

2.1.6 Multi-address Download

Sometimes, it is necessary to download more than one firmware into different addresses of FLASH, SRAM or OTP.

For example, user can follow the steps below to download “Telink.bin” into the address “0x000000” and “0x005000” of FLASH.

Step 1: Select the destination memory space (e.g. FLASH) to store firmware to be downloaded.




Figure 2-28 Select destination space

Step 2: Click “Tool->Multi-address download” or press the shortcut key “Ctrl + P”, so as to open the “Multi-address Download” interface.





Figure 2-29 Open “Multi-address Download” interface

Step 3: Click the “Add” button so as to add firmware file and set target address.



Step 4: Add the path of firmware 1 to the list and set the offset of starting address to store this firmware.

- 1) First, select the first line (No.1), and click the “File” button to add target bin file (e.g. “Telink.bin”) to the list. The corresponding directory will be shown in the “File Path” column.





Figure 2-30 Add FW

- 2) Then set the offset of starting FLASH address to store this firmware in the “Start Address(H)” column.

To ensure that the destination area for firmware storage is valid, the tool will automatically calculate the firmware size and end address, and then show the calculation result in the “File Size(Bytes)” and “End Address(H)” column.





Figure 2-31 Set offset address

Step 5: Refer to step 4 to add the path of firmware 2 to the list and set the offset of starting address to store this firmware.



Step 6: Click the “Download” button to download the added firmware1 and firmware2 into the specific memory locations of the target board.





Figure 2-32 Start downloading

Step 7: After downloading all firmware into the target board, click the “Reset” button to make program run without the need to power cycle the target board.




Figure 2-33 Reset

2.2 Flash sector erase

The “Flash sector erase” function is used to erase specific flash space starting from specific address in unit of 4kB.

For example, to erase 64kB flash space starting from address 0x040000, user can follow the steps below.

Step1: Click the “Setting” button to open the Setting dialog. Select the “FLASH” setting option.

To set the starting address of flash space to be erased, e.g. 0x040000 (default option: 0x000000), user can either select the offset option (if available) via the drop-down menu of “Erase Flash Addr” or directly input the offset address in the editable box.




Figure 2-34 Select starting address

Step2: To set the size of flash space to be erased in unit of 4kB, e.g. 64kB (default option: 512kB), user can either select the size option (if available) via the drop-down menu of “Sector Erase Size” or directly input the size in the editable box.




Figure 2-35 Set erase size

Step3: Click the “Erase” button to start erasing the specified flash space of the target board.




Figure 2-36 Erase 512kB flash space starting from 0x000000

2.3 Activate MCU

The function of ‘Activate MCU when communication with target board failed’ only applies to Swire connection between **“Burning EVK”** and target board in **“EVK”** mode, i.e. it does NOT support **“USB”** mode or USB connection between **“Burning EVK”** and target board in **“EVK”** mode.

When firmware burning fails, please ensure the target board is connected with **“Burning EVK”** via Swire, and then click the “Activate” button to enable this function to activate the MCU.




Figure 2-37 Activate MCU

2.4 Debug

After MCU starts running, to access memory space (flash/core/analog/otp), user can open the “Memory Access” window as shown in Figure 2-38 by directly pressing the shortcut key combination “Ctrl + M”, or by clicking “Tool->Memory Access”.




Figure 2-38 “Memory Access” interface

Table 2-1 Item list of Memory Access

ITEMS	Value list	Default	Shortcut
MCU Type	8366/8368/8266/8267/8269/8232/8233/8x5x	8258	Ctrl+Q
Communication Mode	EVK(Burning EVK)/USB	EVK	Ctrl+W
Operation Destination	FLASH/CORE ¹ /ANALOG ² /OTP	CORE	Ctrl+E
Operation Size (Unit: Byte)	1/2/4/8/16	1	Ctrl+R
Address	0	0	Ctrl+A
Data	0	0	Ctrl+D

¹ CORE includes digital registers and SRAM.

² ANALOG means analog registers.

2.4.1 Access memory

2.4.1.1 Read data from memory space

To read data from specific memory space (FLASH/CORE/ANALOG/OTP), user can follow the steps below:

Step1: Select MCU type (e.g. “8258”) and communication mode (e.g. “EVK”) with target board on the “Memory Access” window.

*Note: If you select “USB” mode to communicate with target board, please ensure that the selected MCU supports USB function and its USB function is available.




Figure 2-39 Select MCU type and communication mode

Step2: Select operation destination (e.g. “CORE”) and set operation size (e.g. “16”) on the “Memory Access” window.

*Notes:

- ✧ If you select “OTP” as operation destination, please ensure that the selected MCU supports “OTP” function.
- ✧ To set operation size, user can either select the size option (if available) via the drop-down menu, or directly set the size in the editable box.
- ✧ The maximum operation size is **1MB**.




Figure 2-40 Set operation destination and size

Step3: Move mouse cursor to the “addr” box, and then input the offset of the starting address to be read (e.g. “0x040000”). Keep the cursor in the “addr” box, by clicking the “Tab” key, user can read data from the specified memory space.

*Notes:

- 1) Every time when clicking the “Tab” key to initiate a memory reading operation, the value of editable box will be saved, so that you can directly select it via the drop-down menu next time.




Figure 2-41 Set starting address and initiate reading

- 2) When reading memory space (e.g. CORE) larger than 1kB, the read data will be automatically saved to a file named “Read.bin” under the “user” folder.

User can also use specific command line to change the name of file to save the read data. Refer to section **2.6 Command line** for details.




Figure 2-42 Save read data

2.4.1.2 Write data into memory space

To write data into specific memory space, user can follow the steps below:

Step1: Select MCU type (e.g. “8258”) and communication mode (e.g. “EVK”) with target board on the “Memory Access” window.

*Note: If you select “USB” mode to communicate with target board, please ensure that the selected MCU supports USB function and its USB function is available.




Figure 2-43 Memory Access Window

Step2: Select operation destination (e.g. “CORE”) and set operation size (e.g. “16”) on the “Memory Access” window.

*Notes:

- ✧ If you select “OTP” as operation destination, please ensure that the selected MCU supports “OTP” function.
- ✧ To set operation size, user can either select the size option (if available) via the drop-down menu, or directly set the size in the editable box.
- ✧ The maximum operation size is **256 bytes**.




Figure 2-44 Set Operation Size

Step3: Move mouse cursor to the “addr” box, and then input the offset of the starting address to be written (e.g. “0x040000”).




Figure 2-45 Offset of the Starting Address

*Note: When operation destination is selected as “CORE”, if the address you set is less than the starting address of “SRAM”, the destination memory space that is actually accessed is digital register; if the address you set is greater than the starting address of “SRAM”, the destination memory space that is actually accessed is SRAM.

Step4: Write data to the specified address.

Move mouse cursor to the “data” box, and then input the target data to be written. Keep the cursor in the “data” box, by clicking the “Enter” key, user can write the specified data into the specified memory space.

*Note: When inputting the data, bytes must be separated from each other with space, as shown below:





Figure 2-46 Set data and initiate writing





2.4.2 Operate Variable List

Before viewing all global variables, please ensure that the “.lst” file and the “.bin” file are placed under the same directory as shown in the following two supported cases.

Case 1: If only one pair of “.lst” file and the “.bin” file are placed under the same directory, this “.lst” file will be selected automatically.

 Interp_Cscript.lst	2018/9/11 10:03	LST 文件	317 KB
 Telink.bin	2018/9/11 10:03	BIN 文件	17 KB

Case 2: if multiple “.lst” files and the “.bin” file are placed under the same directory, the “.lst” file with the name same as the selected “.bin” file will be selected automatically.

 Interp_Cscript.bin	2018/9/11 10:03	BIN 文件	17 KB
 Interp_Cscript.lst	2018/9/11 10:03	LST 文件	317 KB
 Telink.bin	2018/9/11 10:03	BIN 文件	17 KB
 Telink.lst	2018/9/11 10:03	LST 文件	317 KB

For example, if you select the “Telink.bin” file, the “Telink.lst” file will be selected automatically. If there is no “Telink.lst” and only one “xxx.lst” file is placed under the directory containing the selected “Telink.bin” file, this sole “xxx.lst” file will be selected.

2.4.2.1 Update variable list

To look through all global variables, user can select the “Tdebug” page, move mouse cursor to variable list, and then right click the mouse to choose “Refresh” or press the shortcut key “F3”. Each time by pressing “F3” anytime, variable list can be updated once.




Figure 2-47 Update variable list

2.4.2.2 Sort variables

As needed, user can also right click mouse, and choose the “Sort by address” to sort all variables by address from low to high (default), or choose the “Sort by name” to sort all variables by ASCII code value of variable name from A to z (compare the first different character).




Figure 2-48 Sort variable by name

2.4.2.3 View variable above 4 bytes

If a variable's length is larger than 4 bytes, by clicking the "..." in the "Value" column of the "variable list", its value will be available on the right log window.

If a variable's length is greater than 1024 bytes, all values of the variable will be saved in a file named "Read.bin".




Figure 2-49 Read variable value more than 4 bytes

2.4.2.4 Modify variable value

The variable with the length no more than 4 bytes supports direct write operation, which means that its value can be directly modified by double clicking the corresponding box in the “Value” column.

For example, to modify the value of the variable “adc_vref_cfg” in the address “0x41100” to “0x00000004”, user can follow the steps below:

Step 1: Double click the box in the “Value” column corresponding to the specified variable (e.g. “adc_vref_cfg”), so as to make the box become editable.




Figure 2-50 Double click specified “Value” box

Step 2: Input new variable value (e.g. “0x00000025”) to replace the old value (“0x00000004”).




Figure 2-51 Modify variable value

Step3: Press the “Enter” key to write the new value into the specified variable’s address.




Figure 2-52 Write data to specified address

2.4.3 Debug MCU

Before using the buttons including “Run”, “Pause”, “Step” and “PC” to debug MCU, please ensure that the selected MCU supports this function. Refer to section 4 **Function Support List** for details.

In the sub-sections below, the MCU “8258” is taken as an example to introduce this function.

2.4.3.1 Run MCU

After clicking the “Pause” or “Step” button, user can make MCU continue to run from the current position by clicking the “Run” button. Please check the status of MCU by clicking the “PC” button to read PC and ensure program is running again.




Figure 2-53 Run MCU

2.4.3.2 Pause MCU

To view the status of MCU for details, user can click the “Pause” button to stall MCU. Click the “Run” button, MCU will continue to run from the current position.




Figure 2-54 Pause MCU

2.4.3.3 Step MCU

If the communication with target board is available, user can click the “Step” button to view the current position of instruction step by step.

Both “Trace MCU” and “Step MCU” support two modes, as shown below.

- 1) If the “**Single step**” mode is selected, MCU will enter single step mode, in which one PC tracing will be implemented after clicking the “PC” or “Step” button.
- 2) If the “**continuous**” mode is selected, MCU will enter continuous mode and implement continuous PC tracing or make MCU step continuously.

To cancel “**continuous**” mode, user can either switch mode to “**Single step**” mode, or click the “**Run**”/“**Pause**” button.




Figure 2-55 Step MCU in “Single step” mode




Figure 2-56 Step MCU in “continuous” mode

If the target firmware (bin file) and “xxx.lst” file are under the same directory, user can view more details by selecting “View->interp .lst” and clicking the “PC” button to analyze the “xxx.lst” file, as shown below. Refer to section **2.4.2 Operate Variable List**.




Figure 2-57 Select “interp.lst”




Figure 2-58 Step MCU with “interp.lst” selected in “Single step” mode




Figure 2-59 Step MCU with “interp.lst” selected in “continuous” mode

2.4.3.4 Trace PC

If the communication with target board is available, user can click the “PC” button to view the current position of instruction, as shown below:




Figure 2-60 Trace PC in “Single step” mode




Figure 2-61 Trace PC with “interp.lst” selected in “Single step” mode




Figure 2-62 Switch “Single step” mode to “continuous” mode




Figure 2-63 Trace PC with “interp.lst” selected in “continuous” mode

2.4.3.5 Stall MCU

When there is no enough time to view the status of MCU, user can click the “stall” button to stall MCU and view the status of MCU or change the configuration of MCU.




Figure 2-64 Stall MCU

***Note:** In EVK mode, only the EVK burned with the “Firmware_v3.2.bin” (or higher version) supports this function.

2.4.3.6 Start MCU

After stalling MCU, click the “start” button to start MCU, so that MCU will run from the beginning of SRAM.




Figure 2-65 Start MCU

2.5 Single-wire synchronization

Before setting Single wire synchronization speed, please ensure the following items:

- 1) Power supply is normal;
- 2) MCU IS NOT in “**Low Power**” mode;
- 3) Single wire function of MCU is available;
- 4) System clock is normal.

When connection fails to be established between “**Burning EVK**” and the target board, user can try to set Swire (single wire) synchronization speed to improve communication. *Note: Swire register address may vary with different chip types.

- 1) Change the speed of Master and the speed of Slave in the four editable boxes, as shown below. Note that Swire register address may vary with chip types.
- 2) Click the “SWS” button to implement Swire synchronization.




Figure 2-66 Set Swire synchronization speed

Before downloading firmware to target board or debugging MCU, it is suggested that every time on MCU power on, user should implement one Swire synchronization to check whether communication with target board is OK.

If the status of communication with target board is wrong, user can solve the problem according to the methods mentioned at the beginning of section 2.5.

2.6 Command line

User can also use command line to access memory or download file into target board. In the sub-sections below, “read core” is taken as an example.

2.6.1 Single command line

Step 1: Open command line input window by selecting the “Tool->Cmdline Input” or pressing the shortcut key combination “Ctrl + I”.




Figure 2-67 Open cmdline input window

Step 2: Input the needed single command as follows and then press the “Enter” key.
The file with the specified named will be available in the specified location.




Figure 2-68 Enter single command line

2.6.2 Multi-command line

The tool supports multi-command line operation.

All commands need to be separated from each other by semicolon, as shown below.




Figure 2-69 Enter multiple commands

2.7 Log windows

This tool supports USB print function, so MCUs with USB function can use USB print function to output information in log windows on PC side.

Step 1: Click the “View->usb log” to open usb log windows.




Figure 2-70 Open usb log windows

Step 2: In the “usb log” mode, all output characters will be displayed in “Ascii” mode;




Figure 2-71 Display output characters

Step 3: Click the “View->usb log” again to exit the “usb log” mode.




Figure 2-72 Exit usb log mode

2.8 Help

By clicking the “Help->Command line”, all commands will be shown in log windows of the “Download” or “Tdebug” page.




Figure 2-73 Show all commands

By clicking the “Help->User guide”, the embedded “Help” document “**Telink Burning and Debugging Tool (BDT) User Guide**” will be opened, as shown below.




Figure 2-74 Open Help document

To get more information about Telink, user can click the “Help->About Telink”.





Figure 2-75 Get information about Telink

2.9 Default configuration

Open the folder “config” in the root directory of this tool as follows.

名称	修改日期	类型	大小
bin	2018/10/9 15:17	文件夹	
user	2018/10/9 9:31	文件夹	
Cmd_download_tool.exe	2018/10/10 10:24	应用程序	2,197 KB
config.ini	2018/10/9 18:07	INI 文件	3 KB
tl_usb2.0.dll	2017/12/1 14:02	DLL 文件	100 KB

All default configurations in this tool can be changed by modifying the “config.ini” file. Following shows detailed explanations.

```
[MCU]
TYPE 1 0x01 = 8368 \bin\dut_8368_flash_v0244.bin 8000 b010b010 \bin\dut_8366_otp_v0005.bin \bin\dut_8366_otp_normal_v0002.bin End
TYPE 1 0x02 = 8368 \bin\dut_8368_flash_v0246.bin 8000 b010b010 \bin\dut_8368_otp_v0005.bin \bin\dut_8368_otp_normal_v0002.bin End
TYPE 2 0x03 = 8232 \bin\dut_8232_flash_v0002.bin 8000 b010b010 End
TYPE 2 0x04 = 8233 \bin\dut_8233_flash_v0002.bin 8000 b010b010 End
TYPE 2 0x05 = 8266 \bin\dut_8266_flash_v0244.bin 8000 b010b010 End
TYPE 2 0x06 = 8267 \bin\dut_8267_flash_v0002.bin 8000 b010b010 End
TYPE 3 0x07 = 8255 \bin\dut_8255_flash_v0002.bin 40000 b010b010 End
TYPE 3 0x08 = 8258 \bin\dut_8258_flash_v0003.bin 40000 b010b010 End
default = 8258 End
```

① MCU Type:8368

② The path of the firmware: \bin\dut_8368_flash_v0246.bin

This firmware is used to operate flash, e.g. download the specified firmware into flash, read/write flash, erase sectors of flash and check flash data when downloading firmware to flash or erase some sector of flash

③ SRAM Starting Address: 0x8000, e.g.8258:0x40000;

④ Single wire communication:

- 1) Swire register base address of master device:0xb0
- 2) Swire clock of master device:0x10
- 3) Swire register base address of slave device:0xb0
- 4) Swire clock of slave device:0x10

⑤ The path of the firmware:

Firmware1: \bin\dut_8368_otp_v0005.bin, which is used to operate OTP, e.g. download firmware to OTP, read/write OTP, check OTP data during writing data to OTP or downloading firmware to OTP or write data to OTP

Firmware2: \bin\dut_8368_otp_normal_v0002.bin, which is used to check OTP data during downloading firmware to OTP or write data to OTP

⑥ default: 8258

```
[MODE]
MODE 0x01 = USB End
MODE 0x04 = EVK End
default = EVK End
```

① Mode of Communication: USB

② default: EVK(Burning EVK)

```
[OBJ]
OBJ 0x01 = FLASH End
OBJ 0x02 = CORE End
OBJ 0x03 = ANALOG End
OBJ 0x04 = OTP End
default = CORE End
```

① Access Objection: FLASH

② default: CORE

```
[SIZE]
SIZE 0x01 = 1 End
SIZE 0x02 = 1 End
SIZE 0x03 = 1 End
SIZE 0x04 = 8 End
SIZE 0x05 = 16 End
default = 1 End
```

- ① Size of Read / Write data: 2
- ② default: 1

```
[DOWNLOAD_ADDR]
DOWNLOAD 0x01 = 0 End
DOWNLOAD 0x02 = 20000 End
DOWNLOAD 0x03 = 40000 End
default = 0 End
```

- ① Download address: 0x20000
- ② default: 0

```
[ERASE_ADDR]
ERASE 0x01 = 0 End
ERASE 0x02 = 20000 End
ERASE 0x03 = 40000 End
default = 0 End
```

- ① Erase address: 0x20000
- ② default: 0

```
[PAGE_DISPLAY]
PAGE 0x01 = 1 Download End
PAGE 0x02 = 1 Tdebug End
PAGE 0x03 = 2 Log windows End
default = 0 End
```

- ① Page Display: 1 - Tdebug
- ② default: 0 - Download

```
[BUTTON]
Button 1 = example1 external_exe E:\1_wtcd\tcdb.exe uart -1 -u End
Button 2 = example2 internal_exe 8266 wf 34000 -e 48k ;8266 rc 00 -s 10 -u; End
Button 3 = example3 external_file E:\1_wtcd\prj\kite\doc\TS5565_AFEpin_description_v1.0.xlsx End
/But 4 End
/But 5 End
/But 6 End
/But 7 End
/But 8 End
/But 9 End
/But 10 End
/But 11 End
/But 12 End
/But 13 End
/But 14 End
```

- ① The Name of Button1: example1
- ② The property of Button1: external executable application
- ③ The Path of external executable application: E:\1_wtcd\tcdb.exe uart -1 -u
- ④ undefined Button: Button4

The property of Button includes three types:

- 1) external_exe: external executable application
- 2) internal_exe: internal executable application, which means this tool.
- 3) external_file: open any external file by default

```
[PATH]
PATH 0x01 = C:\Users\Administrator\Desktop\Telink.bin End
default = 0 End
```

- ① The Path of firmware: "C:\Users\Administrator\Desktop\Telink.bin"

Download this firmware into target board to update firmware. When there're too many file paths, you can directly delete these. However, the first path can't be deleted.

- ② default file path: "C:\Users\Administrator\Desktop\Telink.bin"

3 Upgrade Firmware

User can follow the steps below to upgrade firmware of “**Burning EVK**”.

Step 1: Click “Help->Upgrade” to open the dialog window “Upgrade EVK”.




Figure 3-1 “Upgrade EVK” window

Step 2: Click the button “Read FW Version” to check the current firmware version.




Figure 3-2 Check current FW version

Step 3: Click the “Load...” button to load the new firmware.




Figure 3-3 Load new FW

Step 4: Click the “Upgrade” button to upgrade the new firmware into the “Burning EVK”. Note: User MUST power cycle the EVK before using it.




Figure 3-4 Upgrade FW into EVK

4 Function Support List

Not all MCU types support all functions of this tool. Please refer to the table below.

Table 4-1 Function Support List

MCU Type ITEMS	8266			8267/8269			8366/8368			8232/8233	8258		
	USB	SWIRE	SWIRE2USB	USB	SWIRE	SWIRE2USB	USB	SWIRE	SWIRE2USB	SWIRE	USB	SWIRE	SWIRE2USB
Download(Flash/SRAM)	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
Download(OTP)	×	×	×	×	×	×	✓	✓	✓	×	×	×	×
Erase FLASH	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
Activate	×	✓	×	×	✓	×	×	✓	×	✓	×	✓	×
PC	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
Run/pause/step	×	×	×	✓	✓	✓	×	×	×	✓	✓	✓	✓
Memory access (OTP)	×	×	×	×	×	×	✓	✓	✓	×	×	×	×
Memory access (FLASH/CORE/ANALOG)	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓